

## The Live View (v6 features)

### Phasing Conception

#### In few words

The Live view allows you to create 2D representations of your project and to export them in video.

#### Access

Access to the Live View from the Create phasing tab.

**Create phasing**

Drawings: Manage Areas/Axes shapes, Connected objects

Zoom: 4.13, Set a scale

Cursor coordinates [lon : -87.24836735093689 lat: 84.29628895647933]


**Gantt chart** Tasks Connected objects on selected drawing

Name (ID)	Start	End	Advanced Filter	Task field	Style par déf...	Live View	Remove live view filter
Projet Demo ()	17/04/2019	21/02/2020					
Sous-projet par défaut (PM-00001) - Def...	17/04/2019	21/06/2019					
Phase 1 : Giratoire Nord	17/04/2019	03/05/2019					
Installations et signalisation	22/05/2019	24/05/2019					
Démolition bordures et pavés	22/05/2019	24/05/2019					

2019

Mar	Apr	May
11 12 13 14 15 16 17 18 19 20 21 22		

2



## Play your project

Visualize your project by clicking on the Play button ► in the bottom right corner. Modify the dates to choose a specific moment. You can also modify the duration. Display another drawing or printed zone with the dropdown list in the left.





## Gantt

The Live view is open in another window than Phase Manager. So you can see your Gantt in Phase Manager in the same time (It's recommended to have 2 screens). Once the Live View is open, a cursor will appear in your Gantt. Its size corresponds to the time interval for the period displayed on the Live View, and its location corresponds to the dates of this period. It is possible to change the time interval and cursor location manually. However, during the video playing, the cursor will take over the parameters entered. The filters entered in your Gantt are also applied in Live View.

## Settings


### Viewing

You can change Live View settings via the Settings button . This window allows you to configure the objects/annotations to be displayed during Live view playing, as well as the time interval for it.



## Titling

The Titling tab lets you display the name of the subproject during playback.



## Capture


Pause playback and take a screenshot of your phasing at a specific moment by clicking the button



## Highlight on the schedule


Pause while playing and highlight the relevant activities at that moment in your Gantt. A filter will be automatically created in the Gantt.

To deactivate the filter, from the Phase Manager window, click on the Remove Live View filter button.



## Studio Mode

Click the button on the left to switch to Studio mode. The Studio mode allows you to visualize your project on different drawings at different times of it.




## Add a drawing or a print area

Click the Add print area button and choose the desired print plan or area. Configure each plan by clicking on it and modifying the dates and/or duration.



## Transition

Add a transition by clicking on a the bar representing your drawing. You will be able to modify the Before and After transition if a drawing is present before or after the selected one. You can also decrease or increase the duration of the transition by moving the cursor directly over the transition representation.



## Export the video

You can export the created video by clicking the Export Video button at the bottom left and then clicking Start. You will be able to modify the name of the video as well as the path where it will be saved on your PC. Set the quality of your video. The higher the quality, the more space the video will take up.

