

## Areas and axes management


### Create Phasing

- [Introduction](#)
- [Drawings management](#)
- [GIS management](#)
- **[Areas and axes management](#)**
- [Areas Categories \(New in v7\)](#)
- [Print areas management](#)
- [Tasks management](#)
- [Connected objects management](#)
- [Mobile pictograms \(v6 features\)](#)
- [The Gantt chart](#)
- [The Live View \(v6 features\)](#)

### Adding areas


#### Adding an area by drawing a polygon

Click on the “Create area” button in the **Manage Areas/Axes shapes** tab:




Then define your polygon's nodes using the mouse left button. A right-click will close the polygon and finish your area creation.

A window appears to associate the shape you just created to an existing area, or to a new area:




**Beware !** By default the area shape is only attached to the drawing on which it has been drawn. To attach it to other plans, left-click on the area then click on the **Spread** button (here we also associate the area shape to the “Initial situation” drawing):



## Adding axes


### Adding an axis by drawing its segments

Click on the “Create axis” button in the **Manage Areas/Axes shapes** tab:




Then define your axis nodes using the mouse left button. A right-click on the drawing will finish your axis creation.

A window appears to associate the shape you just created to an existing axis, or to a new axis:



Note: if the axis segments are displayed in red, it means that the PK of the points that delimit them are not calculated (or that their value is erroneous in the event of a change of direction of the axis for example):




## Definition of the axis direction

The direction of the axis can be seen at its end arrow, which impacts the calculation of the kilometric points (see below):



To change the direction of the axis, right-click on it and choose one of the options (exclusive) **Show start/end arrow** :




If your PKs are no longer consistent, they are displayed in red: repeat the calculation procedure indicated below.


## Calculating the coordinates of an axis' nodes

Phase Manager can automatically calculate the coordinates of the nodes of your axes.


Two cases are possible:

### 1/ You set a scale for your drawing


You must **set the value of one and only one point** of your axis, then click on the "Calculate coordinates" button  in the **Manage Areas/Axes shapes** tab :




Phase Manager then calculates the coordinates of the other points of your axis:




## 2/ You don't have a scale set for you drawing

You must **set the value of two points** of your axis, then click on the Calculate coordinates button :




Phase Manager then calculates the coordinates of the other points of your axis:




## KML importation

In the Create phasing interface, select your drawing (here 'Final situation'). Both area shapes “Main facilities” and “Secondary facilities” are already drawn:




It can also be seen in the list of areas in the right panel that areas associated with imported activities have been created, but have no representation on this drawing (the 'Visible' checkbox is missing).

Go to the **Manage Areas/Axes shapes** tab and click on the 'KML' button:



We'll import here the Tutorial areas source EN.kml that lives in the 'Tutoriel' folder of your software.


In the next window, as it is a KML exported from Phase Manager 4, click on NO:



*Note : you would answer YES if the KML was to be exported from Phase Manager 4 in the case of an update of a V4 project to version 5.*

All areas have properly been imported:





Name	Visible	Catégorie
▼ Areas list		
Roundabout North : Sid...	✓	▼
Roundabout North : Sid...	✓	▼
Roundabout North	✓	▼
Roundabout East : Side...	✓	▼
Roundabout East	✓	▼
Roundabout West : Side...	✓	▼
Roundabout West	✓	▼
Roundabout road	✓	▼
Roundabout central pla...	✓	▼
Wall	✓	▼
Road North Lane	✓	▼
Road South Lane	✓	▼
Road	✓	▼

☐ Tick everything       


## Common behavior of areas and axes

### Graphical move

Areas and axes can be moved easily with the mouse.


Be careful, after their creation the areas/axes are locked by default, which is observed with the shape of the padlock-shaped button:

- Open: authorized move
- Closed: move is locked




## Spreading an area/axis to other drawings

To spread a new area/axis on all the drawings, remember to use the **Spread** button which will allow you to choose on which drawings your area/axis will be located.



## Copy/past an area/axis

To copy/paste an area or axis, simply right-click on the shape and choose **Copy** :




Then right-click in an empty space of the drawing, then click on **Paste** . A dialog window will allow you to define a new area (or axis) or associate the new shape with an existing area (or axis).

**Be careful** : your new area/axis will be superimposed on the original  $\Rightarrow$  it's up to you to move it at your convenience.

## Modifying the colors and lines of the areas/axes

The **Properties** button allows you to change the colors and line types of your areas/axes :


**Areas:**


— □ ×

Edit:

---

One color

 #000000

☐

▼

□

▼


☐ Clip a picture
 

1

Clip a picture

▼

Border

 Black

▼

---

Thickness


1.0

▼

OK

Cancel


## Axes :


— □ ×

Edit:

---

One color

 #000000


☐

▼

□

▼

Border

 Black

▼

---

Thickness

5.0

▼

Unit

km

▼

Precision

2


▼

OK

Cancel

## Using the right side panel




## Helps you add areas/axes representations



Name	Visible
▼ Areas list	
Main facilities	<input checked="" type="checkbox"/>
Secondary facilities	<input checked="" type="checkbox"/>
Roundabout North	<input checked="" type="checkbox"/>
Roundabout North : Sidewalks 1	<input checked="" type="checkbox"/>
Roundabout West : Sidewalks	<input checked="" type="checkbox"/>
Roundabout West	<input checked="" type="checkbox"/>

In the right-side pane you can view all the areas/axes of your project as they are added. Areas/axes already associated with a shape have a checkbox “Visible”.





- Adjust the visibility of your existing areas/axes when creating new ones in the same place, so as not to overload the interface and be able to locate them easily.
- Also remember to disable the display of areas/axes labels so that you do not inadvertently click on them:

Manage Areas/Axes shapes	Connected objects
<b>Print area</b>   	<b>Viewing</b> <input checked="" type="checkbox"/> Show areas <input checked="" type="checkbox"/> Show axes <input type="checkbox"/> Show Areas/Axes names <input type="checkbox"/> Show KP

## Reorganize areas in the Areas list

Once all the areas/axes have been created, you can reorganize them hierarchically. Simply drag and drop into the side panel.

You will get a result as follows:

   	
Name	Visible
▼ Areas list	
Main facilities	<input checked="" type="checkbox"/>
Secondary facilities	<input checked="" type="checkbox"/>
▼ Roundabout North	<input checked="" type="checkbox"/>
Roundabout North : Sidewalks 1	<input checked="" type="checkbox"/>
Roundabout North : Sidewalks 2	<input checked="" type="checkbox"/>
▼ Roundabout West	<input checked="" type="checkbox"/>
Roundabout West : Sidewalks	<input checked="" type="checkbox"/>